

User's Guide For Room 212

You find “Media Link” attached to Desk, it is on left side of the computer's monitor

- **Want to use Computer ONLY.**

Make sure that the “PC” Bottom on the “Media Link” is ON

- **Want to use Projector:**

1. Push “Proj On” on “Media Link” (wait a few seconds until the light is steady)
2. Push “Screen Down” on “Media Link”
3. Select the equipment you want to use; PC, DVD, VCR, Docu or Laptop On “Media Link”.
4. For Audio use “Volume Tuner” on “Media Link”

Turn Off :

1. Push “Proj Off” on Media Link”
2. Push “Screen Up” on Media Link”

Notes:

1. Remotes for DVD Player and VCR are kept in the desk drawer(Labeled Remotes) . Please place them back after you used them.
2. Laptop Users: Connect your laptop to the connection cable coming up from the desk.
3. Audio CD users: use DVD player.

As usual please Do Turn off Projector before you leave.

Problem: Contact MCM 204 , MCM 206c or CIPIT

Media language Center Staffs